

Soft Pouch Camera Gear Fit List

Item	Manufacturer	Model	Soft Pouch Recommendation
Camera	CANON	EOS 1000D / Rebel XS	D-Midsize
Camera	CANON	EOS 100D	D-Midsize
Camera	CANON	EOS 10D/ 20D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 1100D	D-Midsize
Camera	CANON	EOS 1200D	D-Midsize
Camera	CANON	EOS 1300D	D-Midsize
Camera	CANON	EOS 20Da	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 3	D-SLR
Camera	CANON	EOS 300D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 30D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 4000D	D-Midsize
Camera	CANON	EOS 400D/ Digital Rebel XTi	D-Midsize
Camera	CANON	EOS 40D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 450D/ Rebel XSi	D-Midsize
Camera	CANON	EOS 500D	D-Midsize
Camera	CANON	EOS 50D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 550D	D-Midsize
Camera	CANON	EOS 5D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 5D Mark II	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 5D Mark II (With Battery Grip)	D-Pro, D-Pro-Zoom
Camera	CANON	EOS 5D Mark III	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 5D Mark IV	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 5DS	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 5DS R	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 600D	D-Midsize
Camera	CANON	EOS 60D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 650D	D-Midsize
Camera	CANON	EOS 6D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 6D Mark II	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 70D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 750D	D-Midsize
Camera	CANON	EOS 760D	D-Midsize
Camera	CANON	EOS 77D	D-Midsize
Camera	CANON	EOS 7D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 7D Mark II	D-SLR, D-SLR-Zoom
Camera	CANON	EOS 8000D	D-Midsize
Camera	CANON	EOS 80D	D-SLR, D-SLR-Zoom

Camera	CANON	EOS 90D	D-SLR, D-SLR-Zoom
Camera	CANON	EOS D30/D60	D-SLR, D-SLR-Zoom
Camera	CANON	EOS Digital Rebel	D-SLR, D-SLR-Zoom
Camera	CANON	EOS Digital Rebel XT	D-Midsize
Camera	CANON	EOS M6 Mark II	D-Compact
Camera	CANON	EOS R	D-Midsize
Camera	CANON	EOS R5	D-Midsize
Camera	CANON	EOS R6	D-Midsize
Camera	CANON	EOS REBEL K2	D-Midsize
Camera	CANON	EOS Rebel SL1	D-Midsize
Camera	CANON	EOS Rebel SL2	D-Midsize
Camera	CANON	EOS Rebel SL3	D-Midsize
Camera	CANON	EOS REBEL T1i	D-Midsize
Camera	CANON	EOS REBEL T2	D-Midsize
Camera	CANON	EOS Rebel T2i	D-Midsize
Camera	CANON	EOS Rebel T3	D-Midsize
Camera	CANON	EOS Rebel T3i	D-Midsize
Camera	CANON	EOS Rebel T4i	D-Midsize
Camera	CANON	EOS Rebel T5	D-Midsize
Camera	CANON	EOS Rebel T5i	D-Midsize
Camera	CANON	EOS Rebel T6	D-Midsize
Camera	CANON	EOS Rebel T6i	D-Midsize
Camera	CANON	EOS Rebel T6s	D-Midsize
Camera	CANON	EOS Rebel T7	D-Midsize
Camera	CANON	EOS Rebel T7i	D-Midsize
Camera	CANON	EOS Rebel T8i	D-Midsize
Camera	CANON	EOS REBEL Ti	D-Midsize
Camera	CANON	EOS RP	D-Midsize
Camera	CANON	EOS-1V / 1VHS	D-SLR
Camera Kit	CANON	EOS R Mirrorless Digital Camera with 24-105mm Lens	D-Midsize
Camera Kit	CANON	EOS Rebel T8i DSLR Camera with 18-55mm Lens	D-Midsize
Camera	CANON	Kiss X8i	D-Midsize
Camera	CANON	PowerShot G1 X	D-Compact
Camera	CANON	PowerShot S5 IS	D-Compact
Camera	CANON	PowerShot SX70 HS	D-Midsize
Camera	CASIO	EX-FH20	D-Compact
Camera	CASIO	EX-FH25	D-Compact
Camera	CONTAX	N1	D-SLR, D-SLR-Zoom

Camera	CONTAX	NX	D-SLR, D-SLR-Zoom
Camera	FUJIFILM	GFX 50R	D-SLR, D-SLR-Zoom
Camera	FUJIFILM	GFX 50S	D-SLR, D-SLR-Zoom
Camera	FUJIFILM	HS10 / HS11	D-Midsized
Camera	FUJIFILM	HS20 / HS22	D-Midsized
Camera	FUJIFILM	HS30 EXR	D-Midsized
Camera	FUJIFILM	HS35 EXR	D-Midsized
Camera	FUJIFILM	IS-1	D-Midsized
Camera	FUJIFILM	IS-Pro	D-SLR, D-SLR-Zoom
Camera	FUJIFILM	S1	D-Midsized
Camera	FUJIFILM	S1000fd	D-Midsized
Camera	FUJIFILM	S100fs	D-Midsized
Camera	FUJIFILM	S200EXR	D-Midsized
Camera	FUJIFILM	S5 Pro	D-SLR, D-SLR-Zoom
Camera	FUJIFILM	S6500fd	D-Midsized
Camera	FUJIFILM	S700	D-Small
Camera	FUJIFILM	S7000	D-Offset
Camera	FUJIFILM	S8000fd/ S810fd	D-Small
Camera	FUJIFILM	S9000	D-Midsized
Camera	FUJIFILM	S9600/ S9100	D-Midsized
Camera	FUJIFILM	SL1000	D-Midsized
Camera	FUJIFILM	X100	D-Compact
Camera	FUJIFILM	X-A1	D-Compact
Camera	FUJIFILM	X-A10	D-Compact
Camera	FUJIFILM	X-A2	D-Compact
Camera	FUJIFILM	X-A3	D-Compact
Camera	FUJIFILM	X-A5	D-Compact
Camera	FUJIFILM	X-A7	D-Compact
Camera	FUJIFILM	X-H1	D-Midsized
Camera	FUJIFILM	X-M1	D-Compact
Camera	FUJIFILM	X-S1	D-Midsized
Camera	FUJIFILM	X-T1	D-Midsized
Camera	FUJIFILM	X-T1 IR	D-Midsized
Camera	FUJIFILM	X-T2	D-Midsized
Camera	FUJIFILM	X-T3	D-Midsized
Camera Kit	FUJIFILM	X-T3 with 18-55 Lens	D-Midsized
Camera	FUJIFILM	X-T4	D-Midsized
Camera	HP	PhotoSmart 945 (Q2200A)/ 945xi	D-Compact
Camera	KODAK	PIXPRO AZ901	D-Midsized
Camera	LEICA	Digilux 1	D-Compact
Camera	LEICA	Digilux 3	D-SLR, D-SLR-Zoom
Camera	LEICA	R8/ R9	D-SLR
Camera	LEICA	S2	D-SLR, D-SLR-Zoom

Camera	LEICA	SL (Typ 601)	D-SLR, D-SLR-Zoom
Camera	LEICA	SL2	D-SLR, D-SLR-Zoom
Camera	LEICA	V-LUX (Typ 114)	D-Midsize
Camera	LEICA	V-Lux 1	D-SLR, D-SLR-Zoom
Camera	MINOLTA	DiMAGE RD 3000	D-SLR, D-SLR-Zoom
Camera	MINOLTA	Maxxum 3 Date	D-Midsize
Camera	MINOLTA	Maxxum 4/ Maxxum 5	D-Midsize
Camera	MINOLTA	Maxxum 5D	D-Midsize
Camera	MINOLTA	Maxxum 70	D-Midsize
Camera	MINOLTA	Maxxum 7D	D-SLR, D-SLR-Zoom
Camera	MINOLTA	Maxxum 9	D-SLR, D-SLR-Zoom
Camera	MINOLTA	Maxxum HTsi Plus	D-Midsize
Camera	MINOLTA	Maxxum Qtsi/ Stsi/ Xtsi	D-Midsize
Camera	MINOLTA	Vectis S1	D-Midsize
Camera	MINOLTA	Vectis S100	D-Compact
Camera	NIKON	1 AW1	D-Compact
Camera	NIKON	1 J1	D-Compact
Camera	NIKON	1 J2	D-Compact
Camera	NIKON	1 J3	D-Compact
Camera	NIKON	1 J4	D-Compact
Camera	NIKON	1 J5	D-Compact
Camera	NIKON	1 S1	D-Compact
Camera	NIKON	1 S2	D-Compact
Camera	NIKON	1 V1	D-Compact
Camera	NIKON	1 V2	D-Compact
Camera	NIKON	1 V3	D-Compact
Camera	NIKON	COOLPIX 5400	D-Compact
Camera	NIKON	COOLPIX P1000	D-SLR-Zoom
Camera	NIKON	COOLPIX P7800	D-Compact
Camera	NIKON	COOLPIX P80	D-Compact
Camera	NIKON	COOLPIX P900	D-SLR
Camera	NIKON	Coolpix P950	D-SLR
Camera	NIKON	D100	D-SLR, D-SLR-Zoom
Camera	NIKON	D200	D-SLR, D-SLR-Zoom
Camera	NIKON	D300 / D300S	D-SLR, D-SLR-Zoom
Camera	NIKON	D3000	D-Midsize
Camera	NIKON	D3100	D-Midsize
Camera	NIKON	D3200	D-Midsize
Camera	NIKON	D3300	D-Midsize
Camera	NIKON	D3400	D-Midsize
Camera	NIKON	D3500	D-Midsize

Camera Kit	NIKON	D3500 DSLR Camera with 18-55mm and 70-300mm Lenses	D-Midsize
Camera Kit	NIKON	D3500 DSLR Camera with 18-55mm Lens	D-Midsize
Camera	NIKON	D40/ D40X/ D60	D-Midsize
Camera	NIKON	D50	D-Midsize
Camera	NIKON	D500	D-SLR, D-SLR-Zoom
Camera	NIKON	D5000	D-Midsize
Camera	NIKON	D5100	D-Midsize
Camera	NIKON	D5200	D-Midsize
Camera	NIKON	D5300	D-Midsize
Camera	NIKON	D5500	D-Midsize
Camera	NIKON	D5600	D-Midsize
Camera	NIKON	D600	D-SLR, D-SLR-Zoom
Camera	NIKON	D610	D-SLR, D-SLR-Zoom
Camera	NIKON	D70	D-SLR, D-SLR-Zoom
Camera	NIKON	D700	D-SLR, D-SLR-Zoom
Camera	NIKON	D7000	D-SLR, D-SLR-Zoom
Camera	NIKON	D70s	D-SLR, D-SLR-Zoom
Camera	NIKON	D7100	D-SLR, D-SLR-Zoom
Camera	NIKON	D7200	D-SLR, D-SLR-Zoom
Camera	NIKON	D750	D-SLR, D-SLR-Zoom
Camera	NIKON	D7500	D-SLR, D-SLR-Zoom
Camera	NIKON	D780	D-SLR, D-SLR-Zoom
Camera	NIKON	D80/ D90	D-Midsize
Camera	NIKON	D800/ D800E/ D810	D-SLR, D-SLR-Zoom
Camera	NIKON	D810A	D-SLR, D-SLR-Zoom
Camera	NIKON	D850	D-SLR, D-SLR-Zoom
Camera	NIKON	Df	D-SLR, D-SLR-Zoom
Camera	NIKON	DL24-500 f/2.8-5.6	D-Midsize
Camera	NIKON	F100	D-SLR, D-SLR-Zoom
Camera	NIKON	F6 Film SLR	D-SLR
Camera	NIKON	FM10/ FM2N/ FM3A	SLR Manual
Camera	NIKON	N55/ N75	D-Midsize
Camera	NIKON	N60/ N70	D-SLR, D-SLR-Zoom
Camera	NIKON	N90s	D-SLR, D-SLR-Zoom
Camera	NIKON	Z5	D-Midsize
Camera	NIKON	Z50	D-Midsize
Camera	NIKON	Z6	D-Midsize

Camera Kit	NIKON	Z6 with 24-70mm Lens	D-Midsize
Camera	NIKON	Z7	D-Midsize
Camera Kit	NIKON	Z7 with 24-70mm Lens	D-Midsize
Camera	OLYMPUS	E-330	D-Midsize
Camera	OLYMPUS	E-400/ E-410/ E-420/ E-430 E-450	D-Midsize
Camera	OLYMPUS	E-5	D-SLR, D-SLR-Zoom
Camera	OLYMPUS	E-500	D-Midsize
Camera	OLYMPUS	E-510/ E-520	D-Midsize
Camera	OLYMPUS	E-620	D-Midsize
Camera	OLYMPUS	E-M5	D-Compact
Camera	OLYMPUS	E-P1/ E-P2	D-Compact
Camera	OLYMPUS	E-P3	D-Compact
Camera	OLYMPUS	E-PL1/ E-PL1s	D-Compact
Camera	OLYMPUS	E-PL2	D-Compact
Camera	OLYMPUS	E-PL3	D-Compact
Camera	OLYMPUS	E-PL7	D-Compact
Camera	OLYMPUS	E-PL8	D-Compact
Camera	OLYMPUS	E-PM1	D-Compact
Camera	OLYMPUS	OM-D E-M10 II	D-Compact
Camera	OLYMPUS	OM-D E-M10 III	D-Compact
Camera	OLYMPUS	OM-D E-M5	D-Compact
Camera	OLYMPUS	OM-D E-M5 II	D-Compact
Camera	OLYMPUS	OM-D E-M5 III	D-Compact
Camera	OLYMPUS	PEN E-P5	D-Compact
Camera	OLYMPUS	PEN E-PL10	D-Compact
Camera	OLYMPUS	PEN E-PL5	D-Compact
Camera	OLYMPUS	PEN E-PL9	D-Compact
Camera	OLYMPUS	PEN E-PM2	D-Compact
Camera	OLYMPUS	PEN-F	D-Compact
Camera	OLYMPUS	SP-550 UZ	D-Compact
Camera	OLYMPUS	SP-560 UZ	D-Compact
Camera	OLYMPUS	SP-565 UZ	D-Compact
Camera	OLYMPUS	SP-570 UZ	D-Compact
Camera	OLYMPUS	SP-610UZ	D-Compact
Camera	OLYMPUS	SP-620 UZ	D-Compact
Camera	OLYMPUS	SP-720UZ IHS	D-Compact
Camera	OLYMPUS	Stylus 1	D-Compact
Camera	OLYMPUS	Stylus 1s	D-Compact
Camera	OLYMPUS	Stylus SP-100	D-Midsize
Camera	PANASONIC LUMIX	DC-FZ1000 II	D-Midsize
Camera	PANASONIC LUMIX	DC-G100/ Lumix DC-G110	D-Compact

Camera	PANASONIC LUMIX	DC-G9	D-Midsize
Camera	PANASONIC LUMIX	DC-G95 / Lumix DC-G90	D-Midsize
Camera	PANASONIC LUMIX	DC-GH5 / DC-GH5S	D-SLR, D-SLR-Zoom
Camera	PANASONIC LUMIX	DC-GX9	D-Compact
Camera	PANASONIC LUMIX	DC-S1 / DC-S1R	D-SLR, D-SLR-Zoom
Camera Kit	PANASONIC LUMIX	DC-S1 Mirrorless Digital Camera with 24-105mm Lens	D-SLR
Camera Kit	PANASONIC LUMIX	DC-S1R Mirrorless Digital Camera with 24-105mm Lens	D-SLR
Camera	PANASONIC LUMIX	DC-S1H	D-SLR, D-SLR-Zoom
Camera	PANASONIC LUMIX	DMC-FZ100	D-Compact
Camera	PANASONIC LUMIX	DMC-FZ1000	D-SLR, D-SLR-Zoom
Camera	PANASONIC LUMIX	DMC-FZ2000	D-SLR, D-SLR-Zoom
Camera	PANASONIC LUMIX	DMC-FZ2500	D-SLR, D-SLR-Zoom
Camera	PANASONIC LUMIX	DMC-FZ3/ FZ4/ FZ5/ FZ5K/ FZ5S/ FZ4S	D-Small
Camera	PANASONIC LUMIX	DMC-FZ300	D-Midsize
Camera	PANASONIC LUMIX	DMC-FZ30K/ FZ30S/ FZ50	D-Midsize
Camera	PANASONIC LUMIX	DMC-FZ47 / FZ48	D-Compact
Camera	PANASONIC LUMIX	DMC-FZ70	D-Midsize
Camera	PANASONIC LUMIX	DMC-FZ7K/ FZ7S	D-Small
Camera	PANASONIC LUMIX	DMC-FZ8	D-Small
Camera	PANASONIC LUMIX	DMC-FZ80	D-Midsize
Camera	PANASONIC LUMIX	DMC-G1 / G2 / G10	D-Midsize

Camera	PANASONIC LUMIX	DMC-G3	D-Compact
Camera	PANASONIC LUMIX	DMC-G6	D-Midsize
Camera	PANASONIC LUMIX	DMC-G7	D-Midsize
Camera	PANASONIC LUMIX	DMC-G85	D-Midsize
Camera	PANASONIC LUMIX	DMC-GF1	D-Compact
Camera	PANASONIC LUMIX	DMC-GF2	D-Compact
Camera	PANASONIC LUMIX	DMC-GF3	D-Compact
Camera	PANASONIC LUMIX	DMC-GF5	D-Compact
Camera	PANASONIC LUMIX	DMC-GF7	D-Compact
Camera	PANASONIC LUMIX	DMC-GH1	D-Midsize
Camera	PANASONIC LUMIX	DMC-GH2	D-Midsize
Camera	PANASONIC LUMIX	DMC-GH3	D-Midsize
Camera	PANASONIC LUMIX	DMC-GH4	D-Midsize
Camera	PANASONIC LUMIX	DMC-GH5	D-SLR, D-SLR-Zoom
Camera	PANASONIC LUMIX	DMC-GM1	D-Compact
Camera	PANASONIC LUMIX	DMC-GX1	D-Compact
Camera	PANASONIC LUMIX	DMC-GX7	D-Compact
Camera	PANASONIC LUMIX	DMC-GX8	D-Midsize
Camera	PANASONIC LUMIX	DMC-GX85/ GX80/ GX7	D-Compact
Camera	PANASONIC LUMIX	DMC-GX850	D-Compact
Camera	PANASONIC LUMIX	DMC-L1	D-SLR, D-SLR-Zoom
Camera	PANASONIC LUMIX	DMC-L10	D-Midsize
Camera	PANASONIC LUMIX	DMC-LC5K/ DMC-LC5S	D-Midsize
Camera	PANASONIC LUMIX	DMC-LX100	D-Compact

Camera	PENTAX	*ist	D-Midsize
Camera	PENTAX	*ist D	D-Midsize
Camera	PENTAX	*ist DS/ *ist DL/ *istDL2	D-Midsize
Camera	PENTAX	K-1 MARK II	D-Midsize
Camera	PENTAX	K100D/ K110D	D-Midsize
Camera	PENTAX	K10D	D-SLR, D-SLR-Zoom
Camera	PENTAX	K20D/ K200D	D-Midsize
Camera	PENTAX	K-3	D-Midsize
Camera	PENTAX	K-3 II	D-Midsize
Camera	PENTAX	K-30	D-Midsize
Camera	PENTAX	K-5	D-Midsize
Camera	PENTAX	K-5 II	D-Midsize
Camera	PENTAX	K-5 IIs	D-Midsize
Camera	PENTAX	K-50	D-Midsize
Camera	PENTAX	K-500	D-Midsize
Camera	PENTAX	K-7	D-Midsize
Camera	PENTAX	K-m 2000 / K2000	D-Midsize
Camera	PENTAX	KP	D-Midsize
Camera	PENTAX	K-r	D-Midsize
Camera	PENTAX	K-S1	D-Midsize
Camera	PENTAX	K-S2	D-Midsize
Camera	PENTAX	K-x	D-Midsize
Camera	PENTAX	PZ-1P	D-SLR, D-SLR-Zoom
Camera	PENTAX	X-5	D-Midsize
Camera	RICOH	Caplio 500g Wide/ 500SE	D-Compact
Camera	SAMSUNG	Galaxy NX	D-Compact
Camera	SAMSUNG	GX-10	D-SLR, D-SLR-Zoom
Camera	SAMSUNG	GX-1S/ GX 1L	D-Midsize
Camera	SAMSUNG	GX-20	D-SLR, D-SLR-Zoom
Camera	SAMSUNG	NX1	D-SLR, D-SLR-Zoom
Camera	SAMSUNG	NX10	D-Compact
Camera	SAMSUNG	NX100	D-Compact
Camera	SAMSUNG	NX1000	D-Compact
Camera	SAMSUNG	NX20	D-Midsize
Camera	SAMSUNG	NX200 / NX210	D-Compact
Camera	SAMSUNG	NX2000	D-Compact
Camera	SAMSUNG	NX30	D-Midsize
Camera	SAMSUNG	NX5	D-Compact
Camera	SAMSUNG	NX500	D-Compact
Camera	SAMSUNG	PRO815	D-Midsize
Camera	SAMSUNG	WB2100F	D-Compact
Camera	SAMSUNG	WB5000	D-Compact

Camera	SIGMA	sd Quattro H / sd Quattro	D-SLR, D-SLR-Zoom
Camera	SIGMA	SD1	D-SLR, D-SLR-Zoom
Camera	SIGMA	SD1 Merrill	D-SLR, D-SLR-Zoom
Camera	SIGMA	SD10	D-SLR, D-SLR-Zoom
Camera	SIGMA	SD14	D-SLR, D-SLR-Zoom
Camera	SIGMA	SD15	D-SLR, D-SLR-Zoom
Camera	SIGMA	SD9	D-SLR, D-SLR-Zoom
Camera	SONY	Alpha 7	D-Compact
Camera	SONY	Alpha 7 II	D-Midsized
Camera	SONY	Alpha 7R	D-Compact
Camera	SONY	Alpha 7R II	D-Midsized
Camera	SONY	Alpha 7S	D-Compact
Camera	SONY	Alpha 7S III	D-Midsized
Camera	SONY	Alpha A100 / A200 / A290	D-Midsized
Camera	SONY	Alpha A230 / A330 / A380 / A390	D-Midsized
Camera	SONY	Alpha A300 / A350	D-Midsized
Camera	SONY	Alpha A3000	D-Offset
Camera	SONY	Alpha A450 / A500 / A550 / A580	D-SLR, D-SLR-Zoom
Camera	SONY	Alpha A5000	D-Compact
Camera	SONY	Alpha A5100	D-Compact
Camera	SONY	Alpha A600 / A6000	D-Compact
Camera	SONY	Alpha a6100	D-Compact
Camera	SONY	Alpha a6600	D-Compact
Camera	SONY	Alpha a68	D-SLR, D-SLR-Zoom
Camera	SONY	Alpha a7 III	D-Midsized
Camera	SONY	Alpha A700	D-SLR, D-SLR-Zoom
Camera	SONY	Alpha a7R III	D-Midsized
Camera	SONY	Alpha a7R IV	D-Midsized
Camera	SONY	Alpha a7S II	D-Midsized
Camera	SONY	Alpha A850	D-SLR, D-SLR-Zoom
Camera	SONY	Alpha a9	D-Midsized
Camera	SONY	Alpha a9 II	D-Midsized
Camera	SONY	Alpha A900	D-SLR, D-SLR-Zoom
Camera	SONY	Alpha a99 II	D-SLR, D-SLR-Zoom
Camera	SONY	Alpha NEX-5R	D-Compact
Camera	SONY	Alpha NEX-5T	D-Compact
Camera	SONY	Alpha NEX-6	D-Compact
Camera	SONY	DSC-F707	D-Midsized

Camera	SONY	DSC-F717	D-Midsize
Camera	SONY	DSC-F828	D-Midsize
Camera	SONY	DSC-H400	D-Midsize
Camera	SONY	DSC-RX10	Midsize
Camera	SONY	DSC-RX10 II	Midsize
Camera	SONY	DSC-RX10 III	Midsize
Camera	SONY	DSC-RX10 IV	Midsize
Camera	SONY	DSC-V3	D-Compact
Camera	SONY	DSLR-A200	D-Midsize
Camera	SONY	NEX-3 / NEX-5	D-Compact
Camera	SONY	NEX-7	D-Compact
Camera	SONY	NEX-C3	D-Compact
Camera	SONY	NEX-F3	D-Compact
Camera	SONY	SLT A55 / A35 / A33	D-Midsize
Camera	SONY	SLT A57	D-Midsize
Camera	SONY	SLT A65	D-Midsize
Camera	SONY	SLT A77	D-SLR, D-SLR-Zoom
Camera	SONY	SLT A77 MARK II	D-SLR, D-SLR-Zoom
Camera	SONY	SLT-A68	D-SLR, D-SLR-Zoom
Camera	SONY	SLT-A99	D-SLR, D-SLR-Zoom
Camera	TOSHIBA	PDR-M5	D-Compact